instant systems



USER MANUAL

How to Enable Screensaver on the Kiosk

VERSION 26/05

Kiosk Screensaver Setup Guide

This guide explains how to upload and configure a custom screensaver image for a kiosk using Instant Cockpit.

Upload the Image

The uploaded image will be used as the kiosk screensaver.

Navigate to:

Network → Media Upload

Or use the search option



Click **Upload Media** and under **Select Media Type**, choose:

Background Image / Logo



Then:

1. Enter a name for the image in the **Media Name** field.
2. Click **Browse** and select the desired image.
3. Click **Upload**.

Recommended: Use PNG format for best compatibility.



Configure the Screensaver

Navigate to:

Network → Settings → Kiosk Settings



Open the **Kiosk/Location** tab and search for the kiosk you want to configure. Add or update the following keys:

StartPageImage *Defines the screensaver image.*

In the **Value** field, enter the exact image name including the file extension.

Example: myimage.png

ShowStartPageOverlay *Enables the screensaver overlay.*

Set the value to: True

ShowStartPageDetails *Controls whether the logo and Lova QR code remain visible on the screensaver.*

Values:

False = Logo + Lova QR hidden

True = Logo + Lova QR visible



Recommended Image Specifications

Recommended image sizes:

- **700 × 700 px**
- **800 × 1280 px** (recommended for full-screen display)

Supported file formats:

- PNG
- JPG
- JPEG

Localization Settings

By default, the kiosk displays the text:

"Hi! Tap to enter."

If you want to remove this text:

Navigate to the localization settings in Instant Cockpit and locate the following keys:

- start_page_hi
- start_page_tap_to_enter



Remove the existing text by double clicking on that field, enter a single space, and click outside the field to save.

A green indicator confirms the localization was saved successfully.

Note: Only one localization override per keyword is allowed in each database, for example by operator or store.

Apply Changes Immediately

Changes are normally updated automatically after some time. If you want the update to appear immediately:

1. Open the kiosk **Sync** page.
2. Sync both:
    - Settings
    - Files
3. Restart the kioskware through the **Merchandiser View**.


UTILITIES
INVENTORY
Inventory
Restock
Verify Slots
Manual Return
Planograms
Replenishment
Setup Media Box
CABINET SETUP
Calibrate Shelves
Detect Shelves
Manage IqBoxes
Maintenance
Test System
Shelf Status
Utilities
Kiosk Actions
Instructions
Utilities
Utilities are tools to help troubleshoot issues and check cabinet performance.
Tests
Shelves
Sensors
Actions
Settings
Iq Boxes
Chip and Pin:
Override lock until:
1800
Override Lock
Will close down Kioskware so that you can restart it from the top left corner.
RESTART KIOSKWARE
Will reboot the computer.
RESTART COMPUTER
Will shutdown the computer.
SHUTDOWN COMPUTER
Will restart the IQ boxes.
Reboot IQ Boxes
Will stop/start the IQ boxes services.
STOP/START IQ BOXES
Display the cameras stream.
SHOW CAMERAS
Press Maintenance Screen when cabinet is out of service.
MAINTENANCE SCREEN



instant systems

www.instantsystems.se

2026